


10. Check extension housing area for fluid leaks.



2. Position governor body over the oil feed holes of the oil collector body.
3. Install governor body to oil collector body attaching bolts and tighten to specification.
4. Install extension housing as outlined.

## DISASSEMBLY AND ASSEMBLY


**NOTE:** Before beginning the transmission overhaul, review the following guidelines. These general rules are provided to emphasize the need for attention to detail and care when servicing an automatic transmission.

- If the transmission is being removed for major overhaul, it is important to completely clean all transmission components including converter, cooler, cooler lines, main control valve body, governor, all clutches, and all check balls after any transmission servicing that generates contamination. These contaminants are a major cause of recurring transmission troubles and must be removed from the system before the transmission is put back into service.
- Thorough cleaning of the transmission exterior will reduce the possibility that damaging contaminants might enter the sub-assemblies during disassembly and assembly.
- All fasteners must be tightened to specification.
- When building up sub-assemblies, each component part should be lubricated with clean transmission fluid. It is also good practice to lubricate the sub-assemblies as they are installed in the case.
- Needle bearings, thrust washers and seals should be lightly coated with petroleum jelly during sub-assembly buildup or transmission assembly.
- Many components and surfaces in the transmission are precision machined. Careful handling during disassembly, cleaning, inspection and assembly can prevent unnecessary damage to machined surfaces.
- When building up sub-assemblies or assembling the transmission, always use new gaskets and seals.
- The transmission service area should be kept clean, well organized and supplied with clean lint-free shop cloths.
- Whenever a seal is removed from a piston, shaft or servo, note the type of seal and when applicable, the direction of the sealing lip.
- Always use the specified transmission fluid when lubricating seals or other components prior to assembly. Refer to Specifications.

### Governor Removal

1. Remove extension housing as described.
2. Remove governor body to oil collector body attaching bolts.
3. Remove governor body, valve, spring and weight from collector body.


**NOTE:** Components are not retained once the governor body to oil collector body attaching bolts have been removed. It is therefore necessary to hold the governor body and components while removing or installing.



### Installation


1. Assemble governor body and components.

**4.0L Engines**




**THRUST WASHER LOCATION AND IDENTIFICATION  
A4LD TRANSMISSION 4.0L ENGINES**

## 2.3L, 2.9L and 3.0L Engines



THRUST WASHER LOCATION AND IDENTIFICATION  
A4LD TRANSMISSION 2.3L, 2.9L AND 3.0L ENGINES





# Technical Service Information

## KEY TO EXPLODED VIEW — A4LD TRANSMISSION

Ref. No.	Basic Part No.	Description	Ref. No.	Basic Part No.	Description	Ref. No.	Basic Part No.	Description
1	7052	Seal Assy (Ext. Hsg.) Oil	41	E860120-S	Ring — Retaining 4.0L	80	7B442	Plate (Clutch) High
2	7A039	Housing (Extern.)	42	7D191	Retainer — Overrun Cl. Spring 2.3L, 2.9L & 3.0L	81	7B164	Plate Assy. (Clutch) High
3	7D071	Shaft (Parking Pawl)	43	7D170	Spring — Overrun Clutch 2.3L, 2.9L & 3.0L	82	7D428	Washer (Inn. Brake Drum Thrust) — #5
4	7A441	Pawl (Parking)	44	7D422	Washer (O.P. Shaft Hub Thrust #10)	83	E860125-S	Ring 63 mm (High Cl. Pst. In Int. Bk. Drum)
5	7D070	Spring (Parking Pawl Return)	45	7D095	Band Assy. — Reverse	84	7D041	Ret. (Rev. Clutch Piston Spring) — 8 Tabs
6	7D419	Cup — Parking Rod Guide	46	7C498	Drum Assy. (Rev. Brake) 2.3L, 2.9L & 3.0L	85	7C151	Spring (Rev. Clutch Piston) 20 Req'd
7	7D066	Gasket (Ext. Hsg.)	47	E860122-S	Ring 87 mm Retain Forward Ring Gear to Hub	86	7A258	Piston (Rev. Clutch)
8	7D060	Shaft Assy (Output) 4.0L Vehicle, Shaft has no Lube Hole	48	7D164	Hub — Output Shaft — 57 Ext — 34 Int Teeth	87	7A548	Seal (Clutch Piston Oil)
9	E800152-S72	Screw — Extension to Case	49	E861125-S	Retaining Ring 25 x 1.2	88	7D404	Seal (High Clutch Piston Inner)
10	7A300	Body — Gov. Valve	50	7A153	Washer — Output Shaft Ring	89	7D044	Drum Assy (Intern. Brake)
11	7C054	Valve (Governor Primary)	51	7D423	Gear — Output Shaft Thrust — (2 Req'd) #8 and #9	90	7D034	Band Assy (Intern. Servo)
12	7A302	Spring (Governor Valve)	52	7D006	Planet Assy (Rev.)	91	3A8307-S100	Net & Seal — Hex
13	7D324	Weight — (Governor Outer)	53	E860119-S	Ring (Planet to Drum) Except 4.0L	92	7C482	Screw (Rev. Band Adj.)
14	7F124	Counterweight — Governor	54	E860121-S	Ring — 38 mm (Input Shell to Sun Gr. Assy) — (2 Req'd)	93	7D430	Strut (Intern. Bk. Band Anchor)
15	E802164-S72	Boil (Gov. Body to Collector Body) — (2 Req'd)	55	7D066	Washer (Input Shell Thrust) Except 4.0L	94	7D029	Strut (Intern. Bk. Band Apply)
16	E800156-S	Boil — M6 x 20 (Gov. Body to Collector Body) — 2 Req'd	56	7D064	Shell (Input)	95	7D396	Lever (Intern. Band Servo)
17	7D220	Body (Gov. Oil Collection)	57	7D063	Gear Assy (Sun)	96	7D433	Shaft (Intern. Band Act. Lever)
18	7D011	Ring (Gov. Hsg. Seal) — (3 Req'd)	58	7D063	Big. Thrust — Sun Gear Race — RR	97	7D429	Seal Ring (High Clutch) 2 Req'd — Vilon Sel. Fit — #4
19	7B388	Washer (Output Shaft Thrust Gr) — #11	59	7A398	Planet Assy (Fwd)	98	7D014	Washer (Fr. Pump Input Thrust) — Sel. Fit — #4
20	7D261	Lever Assy — Dwn/Sht Del. — Inner	60	7F374	Big. Assy. — Cl. Int. Drum Thrust — #7	99	7G033	Support Assy — Center O/D
21	7E333	Pin — Main. Viv. Del. Lever — Inner	61	7D392	Gear (Ring Fwd) 72 Ext. 57 Int. Teeth	100	E826160-S76	Nut & Cage Assy S/L M6
22	E630020-S	Washer — Flat Steel	62	7D393	Hub (Fwd Ring Gear)	101	E804373	Screw Cap — Hex 8 & M6 x 15
23	7E332	Spring Assy — Main. Viv. Delent	63	E860122-S	Ring — Ret 87 mm (Fwd. Ring Gr. to Hub)	102	71325	Washer (Center Support Thrust) — #3
24	7C494	Lever — Manual Valve	64	7D235	Washer (Fwd. Cl. Hub Thrust) — #6	103	E860366-S	Ring Retaining (Retain 7G033 In Case) Except 4.0L
25	E820112-S	Nut (Lvr. to Lev. Assy Dwn/Sht Del. Inner)	65	7D234	Needle Thrust Bearing #6	104	E860119-S	Ring — Ret. (110.1 mm x 1.6)
26	E662312-S	Clip — Rod Retaining	66	E860115-S	Plate (Clutch Pressure)	105	7A656	Shaft — Center Assy — O/D
27	7D410	Rod Assy — Park Pawl Actv.	67	7B066	Plate (Clutch) Forward	106	7C109	Clutch Assy — Overrun — O/D
28	7B498	Seal Assy — Main Control Lvr. Oil	68	7B442	Plate Assy — Clutch (Fwd)	107	71339	Washer — Over Clutch — O/D
29	E840125-S	Pin — Spring Roller (Retain Outer Man Lvr. Assy)	69	7B164	Plate Assy — Clutch (Fwd)	108	7653	Gear — O/D Ring
30	7A256	Lever Assy — Manual Control	70	7E457	Spring — Forward Clutch Cushion	109	71495	Big. Assy — O/D Inner Race — #2
31	3A6078-S	O Ring — Outer Man Lvr. Shaft Oil	71	E860109-S	Ring 34 mm (Hub to Fwd. Ring Gear)	110	7B446	Carrier Assy — Ptl. Gear — O/D
32	7A394	Lever Assy — Dwn/Sht Ctrl — Outer	72	7D041	Ring (Fwd. Cl. Piston Spring)	111	7D063	Gear Assy — Sun O/D
33	E820109-S72	Nut — Hex M8 x 1 (Outer Man. Lvr. to Shaft)	73	7C151	Spring — Fwd. Cl. Piston (15 Req'd)	112	7660	Adapter — O/D Clutch
34	E800156-S72	Screw M6 x 30 (Valve Body to Case)	74	7A262	Piston Assy (Fwd. Clutch)	113	E860126-S	Ring — Retaining (Sel. Fit)
35	E840115-S	Pin — Rev. Band Anchor (2 Req'd)	75	7A548	Seal (Clutch Piston Oil)	114	7B006	Plate — O/D Clutch Pressure
36	7D034	Vent Assy — Case	76	7D424	Cyl. Assy. (Fwd. Clutch)	115	7B164	Plate Assy — O/D Clutch Int. Spline
37	7D034	Vent Assy — Case	77	7D019	Seal (Fwd Clutch Cyl) — 2 Req'd	116	E860125-S	Ring — Ret. 63 mm (O/D Cl. Pst. to O/D Bk. Drum)
38	7A247	Case Assembly	78	E860126-S	Ret Ring (Select Fit)	117	7D041	Retainer — O/D Cl. Pst. Spring — 8 Tabs
39	7A247	Switch Assy — Gr. Shift Neutral	79	7B066	Plate (Clutch Press Rev)	118	7D041	Retainer — O/D Cl. Pst. Spring — 8 Tabs
40	E853116-S	Seal — O Ring				119	7C151	Spring — O/D Cl. Piston (20 Req'd)
						120	7A258	Piston — O/D Clutch

All light trucks transmissions use (4) E800152-S72 Screws and (2) E804137-S72 Studs.

KEY TO EXPLODED VIEW — A4LD TRANSMISSION (Cont'd.)


121	7A548	Seal — O/D Cl. Piston — Outer	146	7E459	Clamp — TV Control Diaphragm	174	7423	Seal — Rev. Brd. Servo Ret. Oil — Large
122	7D404	Seal — O/D Cl. Piston — Inner	147	E800341-S72	Boil M6 x 12 mm (Valve Clamp to Case)	175	7L173	Gasket — Rev. Servo Sqr. Plate Cover
123	7L669	Drum Assy — O/D	147A	E804533-S	Stud-M6 x M6 x 12.0 (2.9L 4x4 and all 4.0L)	176	7D036	Cover — Rev. Brd. Servo Piston
124A	7D034	Band Assy — O/D 2.9L 2.9L 3.0L	148	7A377	Diaphragm Assy — TV Control	177	E800156-S72	Bot M6 x 20 (Rev. Servo to Vv. Bdy.) 4 Req'd
124B	7F196	Band Assy — O/D 4.0L (not shown)	149	7A380	Rod — TV Control	178	E863137-S	O/Ring — Oil Screen Assy — Small
125	388307-S100	Nut & Seal — Hex	150	E853110-S	O/Ring — Throttle Valve	179	E863132-S	O/Ring — Oil Screen Assy — Large
126	7C492	Screw — O/D Band Adj.	151	7D080	Valve — Throttle Valve	180	7A039	Screen Assy — Oil Pan
127	7D430	Sirt — O/D Brk. Drum Anchor	152	E860343-S	Ring — Ret. 67 x 15 Intermediate	181	7A264	Oil Pan
128	7D029	Sirt — O/D Brk. Drum Apply 2.9L 2.9L & 3.0L	153	E853170-S	O-Ring — Servo Cover to Case — Intern.	182	E800154-S72	Screw — M6 x 45 (Vv. Bdy. to Case) 5 Req'd
129	7D396	Lever — O/D Band Servo	154	7L493	Cover & Seal Assy. Inter. Band Servo	183	E800158-S72	Screw — M6 x 14 (Oil Pan to Case) 18 Req'd
130	7D433	Shaft — O/D Band Adj. Lever	155	7E221	Piston & Rod Assy. — Intermediate	184	14489	Connector — Conv. Cl. Overdrive/3-4 Shift
▲131	7A653	Bracket — O/D	156	7D028	Spring Intern. Band Servo Piston	185	6916	Solenoid Assy — Converter Clutch
132	7D441	Seal (Front Oil Pump)	157	E860344	Ring — Ret. 67 x 15 — O/D	186	6916	Solenoid Assy — 3-4 Shift
133	7D429	Seal (Intern. Brk. Drum) — 2 Req'd	158	E853170-S	Seal — Servo Cover to Case — O/D	187	7A191	Gasket — Oil Pan
134	7D014	Washer (Frt. Pump Input Thrust) Seal, Frt. #1	159	7L493	Cover & Seal Assy. — O/D Band Servo	188	7190	Rubber Overrun Clutch 2.9L 2.9L & 3.0L
135	7L201	Support & Gear Assy (Frt. Pump)	160	7E221	Piston & Rod Assy. — O/D	189	7D225	Plate-Sun Gear Thrust Brg. — Rear
136	7L323	Seal (Front Pump Support)	161	7D028	Spring — O/D Band Servo Piston	190	7M463	Tube-Lube Oil Inlet — Shift
137	7A136	Gasket — Oil Pump	▲163	7A008	Plate — Vv. Bdy. Separating	191	7D226	Washer — Fwd. Ring Gear Thrust — #6
138	78472	Plate (Oil Pump Adaptor)	164	7D100	Gasket — Cont. Vv. Bdy. Separating	191A	7D0901	Washer — Fwd. Clutch Thrust
139	7975	Hsg. Assy — Converter	165	7A100	Control Assy — Main	192	N804798-S100	Connector Assy-Oil Tube — 2 Req'd
140	7A248	Seal Assy (Frt. Oil Pump)	166	E800153-S72	Screw M6 x 40 (Valve Body to Case) 19 Req'd	193	7A045	Integral Thrust Washer 2.9L 2.9L and 3.0L Engage
141	7017	Input Shaft	▲167	7D190	Rod — Rev. Band Servo Piston	194	7C469	Drum Assy (Rev. Brake) 4.0L
142	7902	Converter Assembly	▲168	E830139-S	Ret. — Rev. Servo Cushion Spring	195	7E205	Stud-O/D Brk. Drum Apply (4.0L)
143	E804594-S	Screw M10 x 30 (Conv. Hsg. to Case) 8 Req'd	169	7E207	Spring — Rev. Servo Occurr.	196	7B176	Output Shaft Sleeve (4.0L only)
144	E854104-S	*O-Ring	170	7423	Seal — Rev. Brd. Servo Ret. Oil — Small	197	7C109	Overrun Clutch — Spring Type (4.0L only)
145	E804372-S72	Boil — Fig. Hd. 8.8 x M6 x 35.0 (Pump Suppl. Assy to Conv. as Assy) 5 Req'd	171	7D031	Spring — Rev. Servo Piston			
			172	7D030	Piston & Rod Assy — Rev. Servo			
			▲173	E860167-S	Ring Retainer (Ret. Rod to Piston)			

## Transmission

NOTE: Bolt identification sizes for the following procedures indicate the head size, not the thread size.


### Disassembly

1. Remove torque converter.




2. Remove input shaft.


NOTE: The two splined ends are different.




3. Remove eighteen 13mm bolts, then oil pan.



4. Remove 10mm bolt (M6 x 45mm long) then remove filter screen.
5. Remove detent spring.




6. Disconnect 2 wires at converter clutch solenoid. Disconnect the 2 wires at the 3-4 shift solenoid.




7. Remove twenty five-10mm bolts retaining valve body to case. While easing valve body out of the transmission, unlock and remove selector lever connecting link. Remove valve body and gasket.


NOTE: There are four different lengths of bolts—30mm, 35mm, 40mm and 45mm.




8. Remove 5mm allen-head retaining bolt holding center support.



9. Remove six 17mm bolts and studs, then remove extension housing.




10. Remove the parking pawl and the return spring.






11. Remove two 10mm bolts, then remove governor.




12. Mount transmission in Bench Mounted Holding Fixture T57L-500-B (or equivalent) as shown.

13. Two 10mm bolts, 50mm long will be required.




14. Remove eight 17mm bolts, then remove converter housing and pump as an assembly.


15. Rotate and lift so that clutches will stay in place. Remove the No. 1 thrust washer and the gasket.




16. Remove hydraulic pump oil seal using Seal Remover T74P-77248-A, or equivalent, with a spanner.
17. Remove the hydraulic pump from the converter housing and remove the steel plate (behind oil seal) with the O-ring.




18. Loosen overdrive band lock nut and back off adjusting screw.
19. Lock nut will be discarded and a new nut will be used, as lock nut and seal are one piece.
20. Remove anchor and apply struts.
21. Lift out overdrive clutch assembly and band.  
NOTE: Identify band as "overdrive" and identify either "apply" or "anchor" end for reinstallation in order to distinguish it from the intermediate band. 4.0L applications use a double wrap design band.



22. Lift out overdrive one-way clutch and planetary assembly.




23. Remove center support retaining snap ring.




24. Remove overdrive apply lever and shaft.
25. Remove overdrive control bracket from valve body side of case.


NOTE: The overdrive apply lever does not have a boss on the shaft hole as compared to the intermediate apply lever. The overdrive apply lever shaft is longer as compared to the intermediate apply lever shaft.




26. Remove thrust washer on top of center support.  
NOTE: Identify thrust washer for reassembly.



27. Remove center support being careful to pry upward evenly.




28. Remove thrust washer below center support.  
NOTE: Identify thrust washer for reassembly.



29. Loosen intermediate band lock nut and back off adjusting screw.  
30. Lock nut will be discarded.  
31. Turn transmission in holder, down 90 degrees.  
32. Remove anchor and apply struts.


33. Remove reverse / high and forward clutch assembly.

REVERSE/HIGH  
AND FORWARD  
CLUTCH ASSEMBLY




34. Remove intermediate band.

NOTE: Identify band as "intermediate" and identify which end is "apply" or "anchor" side for reinstallation purposes.




35. Remove forward planet assembly. Depending on application, some vehicles will have transmissions with aluminum planet carrier assemblies and some will have stamped steel planet carrier assemblies.

36. Note and identify No. 6 thrust washer, or thrust bearing.




37. Remove sun gear shell.




38. For all applications except 4.0L; remove large snap ring from reverse planet gear carrier.

NOTE: Transmissions used with 4.0L engines do not use a snap ring at this location.




- 39. Remove reverse planet assembly.
- 40. Note and identify thrust washers on both sides. They are identical.




- a. With 4.0L applications; remove output shaft sleeve (lubricant guide).

OUTPUT  
SHAFT  
SLEEVE




- 41. Remove small snap ring on output shaft.




- 42. Remove output shaft ring gear.


OUTPUT  
SHAFT  
RING GEAR




43. Remove low-reverse drum and one-way clutch assembly.




44. Remove low-reverse servo from valve body side of case.




45. Remove low-reverse band.




46. Remove thrust washer.




NOTE: Inner race of rear one-way clutch is not removable from case.




- 47. Remove intermediate apply lever and shaft.
  - 48. This apply lever has a boss on the shaft hole and the shaft is shorter than the overdrive shaft.
- NOTE: A control bracket is not used.




- 49. Turn transmission so that output shaft points upward.
  - 50. Remove output shaft by pulling upward.
- NOTE: If output shaft is to be replaced, 4.0L applications use an output shaft that does not have a lubricant hole.




- 51. Remove park gear / collector body assembly from rear of case.




- 52. Remove thrust washer.




- 53. Remove one 10mm (M6 x 12mm long) bolt and retainer.
- 54. Remove vacuum diaphragm and throttle valve actuator rod.



55. Verify that the throttle valve moves freely using flat needle nose pliers.
56. Remove throttle valve, using needlenose pliers.




57. Remove intermediate servo cover snap ring.
58. Transmission case is notched out to permit easy snap ring removal.



59. Remove intermediate servo cover, piston and spring.
  60. Remove overdrive servo cover snap ring.
  61. Remove overdrive servo cover, piston and spring.
- WARNING: COVERS CAN POP OFF DUE TO SPRING PRESSURE BEHIND PISTON.**
62. Covers usually can be removed by tapping lightly on cover or side of case.


63. Occasionally, covers must be removed using air pressure.

**CAUTION: Identify the overdrive cover and piston from the intermediate cover and piston. Keep separate or tag for proper installation. Installation in the incorrect bore could cause band concerns due to pressure differences.**



64. Air pressure may be used on release sides of pistons.


**CAUTION: Air pressure should not be greater than 137 kPa (20 psi).**




65. Remove neutral start switch using Neutral Start Switch Socket T74P-77247-A or equivalent.




**CAUTION:** Do not use an open-end wrench. Damage to neutral start switch can result.




66. Remove 13mm kickdown lever nut, lever and O-ring seal.




67. Remove linkage centering pin, taking care not to damage case flange.



68. Remove 7/8 inch nut, manual lever, internal kickdown lever and park pawl rod and detent plate assembly.




69. Remove lever shaft oil seal.



70. Remove case solenoid connector.
71. A tab on the outside of the case on backside of connector must be depressed while pulling with pliers. The tab is depressed with a small pair of locking pliers.

**NOTE:** The connector need not be removed unless it is to be replaced, and / or if the case is to be immersed in a degreaser.



### Assembly


**NOTE:** Before beginning assembly of the transmission, the following high clutch seal sizing procedure must be performed.

1. Install new high clutch seals on the support hub. It is necessary to size these seals.


**NOTE:** The seal grooves have a "dovetail" contour with straight sidewalls on the pressure sealing sides.

**NOTE:** If this is not done, the seals can be cut or rolled over when entering the intermediate brake drum cavity.


Apply a liberal amount of petroleum jelly to the center support hub and seals.




2. Use overdrive brake drum as sizing tool. Carefully rotate the center support while inserting.




3. Observe the seals as they enter the cavity to see that they do not roll over or get cut.




4. Be sure the center support is seated fully into the overdrive drum. Allow to stand for several minutes so that the seals seat in the grooves. Set aside until required for reassembly later in this section.



5. Place thrust washer No. 11 (7B368) into back of case.




6. Install collector body in rear of case.




7. Install output shaft.


NOTE: If a new output shaft is being installed, 4.0L applications use an output shaft that does not have a lubricant hole.



8. Install governor on collector body with two retaining bolts. Tighten to 9-14 N·m (84-120 lb-in).




9. Place thrust washer No. 10 (7D422) into case from the front.




10. Install low-reverse drum using Overrunning Clutch Replacement Guide Tool T74P-77193-A or equivalent.


NOTE: With 4.0L applications, use a "sprag" type overrunning clutch and the replacement guide tool is not required.



11. Install output shaft ring gear and snap ring onto output shaft.  
 NOTE: Always use a new snap ring for assembly.




- a. With 4.0L applications; install the output shaft sleeve (lubricant guide).




12. Install thrust washer No. 9 (7D423), reverse planet assembly and thrust washer No. 8 (7D423).

13. Use petroleum jelly to hold thrust washers in position on planet assembly.




14. Install snap ring in drum to hold planet assembly in place.

NOTE: 4.0L applications do not have a snap ring at this location.




15. Install low-reverse band.




16. Replace servo piston or O-ring if necessary.

17. Install low-reverse servo piston to hold band in position.




18. Replace piston or O-ring if necessary.

19. Install intermediate servo spring, piston, cover and snap ring. Refer to the Specifications portion of this section for proper means of identifying overdrive from intermediate servo covers and components.




20. Replace piston or O-ring if necessary.

21. Install overdrive servo spring, piston, cover and snap ring. Ensure correct cover is installed, as identified by a tag during disassembly.




22. Locate and identify intermediate servo apply lever and shaft.


23. The intermediate servo apply lever is the lever that has a boss on the shaft hole and the shaft is shorter than the overdrive shaft.



24. Install intermediate servo apply lever and shaft into case.




25. Install the complete forward clutch and reverse and high clutch assemblies.




26. Turn transmission so that the output shaft points downward.

27. Install intermediate band and apply strut.




28. Install the intermediate band anchor strut and input shaft (temporarily) as an alignment guide, then go to the transmission rear end play check.



29. The transmission rear end play check determines:


- a. the amount of space existing between the thrust washer surfaces of the overdrive center support and the intermediate brake drum.
- b. the thickness of the No. 4 thrust washer that is required to obtain an end play of 0.30-0.54mm (0.012-0.022 inch).

To perform the end play check, fabricate a depth gauge fixture from a spare overdrive center support. A 3mm (1/8 inch) hole must be drilled through the thrust washer surface of the center support. This allows Depth Micrometer D80P-4201-A or equivalent access to the area between the thrust surfaces of the support and the intermediate brake drum. Remove the rubber seals from the spare center support to allow easy insertion into the intermediate brake drum.







30. Place Depth Micrometer D80P-4201-A or equivalent over drilled hole in the fabricated depth gauge fixture. Extend micrometer probe until it is flush with the thrust washer surface of the fixture. Record the micrometer reading. This is Reading A.




31. Install the depth gauge and input shaft fixture into the intermediate brake drum and make sure it is fully seated in the transmission case. Gently "wiggle" input shaft to allow center support fixture to slide into intermediate brake drum using its own weight. The fixture axially locates the drum in its proper position.



32. Place depth micrometer over the drilled hole in the fixture.



33. Continue extending the micrometer probe until it contacts the thrust washer surface of the intermediate brake drum. This is Reading B.
34. Subtract Reading A from Reading B. The difference between these readings is Dimension A. This is the space between the thrust surfaces.




35. Remove and rotate the fixture 180 degrees. Repeat steps 30 through 34.
36. Average the two Dimension A readings to obtain the final Dimension A reading.
37. Locate the final Dimension A reading in the following chart and select the proper thrust washer required to obtain the specified end play of 0.30-0.54mm (0.012-0.022 inch). If Dimension A is outside the specified limits, this indicates improper assembly, missing parts or parts out of specification. This requires a rebuild of the unit.


## TRANSMISSION END PLAY SELECTIVE THRUST WASHER CHART

Dimension A		Thrust Washer Identification	Thrust Washer Thickness		Thrust Washer Part Number
mm	Inch		mm	Inch	
1.46-1.65	0.057-0.064	A	1.2	0.047	89DT-7D014-HA
1.66-1.85	0.065-0.073	1	1.4	0.055	89DT-7D014-AA
1.86-1.95	0.074-0.077	2	1.6	0.063	89DT-7D014-BA
1.96-2.05	0.078-0.081	3	1.7	0.067	89DT-7D014-CA
2.06-2.15	0.082-0.085	4	1.8	0.071	89DT-7D014-DA
2.16-2.25	0.086-0.089	5	1.9	0.075	89DT-7D014-EA
2.26-2.35	0.090-0.093	6	2.0	0.079	89DT-7D014-FA
2.36-2.45	0.094-0.100	7	2.1	0.083	89DT-7D014-GA
2.46-2.65	0.097-0.104	B	2.2	0.087	89DT-7D014-MA
2.66-2.85	0.105-0.112	C	2.4	0.094	89DT-7D014-JA
2.86-3.05	0.113-0.119	D	2.6	0.102	89DT-7D014-KA
3.06-3.15	0.120-0.096	E	2.8	0.110	89DT-7D014-LA

38. Remove depth gauge and input shaft fixture from overdrive drum. This procedure (sizing of seals) was begun in steps 1 through 4 of this section (Transmission Assembly). Position the correct No. 4 (7D014) selective washer on rear of center support using petroleum jelly.
39. Insert the input shaft (short splines down) through the center support and into the splines in the forward clutch cylinder.




40. Carefully place the center support into the case, but do not start it into the intermediate brake drum. Be sure it is square with the case and the 5mm allen-head bolt retainer nut is oriented with the bolt hole in the case.




41. DO NOT apply any pressure to the center support. Gently "wiggle" the input shaft allowing the center support to slide into the intermediate brake drum using its own weight. Perform this operation until the support is fully seated. Remove the input shaft.

42. Position No. 3 (7L326) thrust washer on top of center support.




43. Install large snap ring to retain center support in position with taper snap ring toward the front of the transmission.

NOTE: The ends of the snap ring should be positioned in the wide shallow cavity located in the five o'clock position.




NOTE: Two types of center support retaining snap rings are used. One is identified by holes located in the inner and outer diameter; the other type of snap ring has no holes. They should be positioned as shown.


"HOLE TYPE" SNAP RING



"NON-HOLE TYPE" SNAP RING




44. Install 5mm allen-head bolt that retains center support to case.




45. Install sun gear and overdrive clutch adapter into overdrive planet assembly and one-way clutch. The part number on the adapter should face the sun gear.

46. Take care to center needle bearing race inside of planetary. Be sure it stays centered, and positioned with the extruded lip in the upward position (toward sun gear).




47. Assemble the overdrive planet and one-way clutch assembly.

- a. The one-way clutch assembly **MUST** be installed into the centershaft in such a way that the flanges of the inner and outer cages are toward the overdrive planet assembly which is toward the front of the transmission.




- b. The overdrive clutch washer, that is positioned between the overdrive planet carrier and centershaft must be installed in such a way that the "recessed ID" faces forward (not against sprag clutch).




- c. To perform the proper assembly buildup check, hold the planet assembly—then the centershaft should turn clockwise.


PROPER ASSEMBLY BUILD UP CHECK  
CENTER SHAFT TURNS CLOCKWISE  
WHEN HOLDING OVERDRIVE  
PLANET ASSEMBLY




48. Install overdrive planet assembly and one-way clutch into case.



49. Install overdrive drum assembly.




50. Install overdrive bracket, apply lever, and shaft.




51. Install overdrive band and apply strut.

NOTE: Ensure correct band is installed as identified by a tag during disassembly.

NOTE: Band and strut for 2.3L, 2.9L and 3.0L applications shown. 4.0L applications use a double wrap design band.




52. Install anchor strut.



53. Verify that needle bearing race in overdrive planetary is centered and overdrive clutch is fully seated.
54. Place No. 1 (7D014) selective washer on top of overdrive clutch drum and temporarily install pump assembly into case. Be sure that it is fully seated in the case.
55. The pump body must be below the level of the case gasket in the case.

NOTE: Check for damaged or missing front pump support seal. Replace if necessary.

NOTE: Rough casting portion of the crescent. This is not a flaw and the pump should NOT be replaced.




NOTE: ROUGH CASTING PORTION OF THE CRESCENT. THIS IS NOT A FLAW AND THE PUMP SHOULD NOT BE REPLACED.

56. Mount Dial Indicator D78P-4201-G or equivalent on the pump with plunger resting on the transmission housing. Set dial indicator to zero.


57. Swing indicator around so plunger contacts the pump. Check dial reading. This reading is the amount of end play. Note reading for later use.
58. Move dial indicator block to opposite side of the pump (180 degrees). Repeat steps 56 and 57.
59. Find average of two readings. This average reading of end play should be from 0.18mm to 0.64mm (0.007 to 0.025 inch). If reading exceeds the limits, change No. 1 selective washer.
60. The available selective washers are:

TRANSMISSION END PLAY SELECTIVE THRUST WASHER CHART


Thrust Washer Thickness		Thrust Washer Identification	Thrust Washer Part Number
mm	Inch		
1.2	0.047	A	89DT-7D014-HA
1.4	0.055	1	89DT-7D014-AA
1.6	0.063	2	89DT-7D014-BA
1.7	0.067	3	89DT-7D014-CA
1.8	0.071	4	89DT-7D014-DA
1.9	0.075	5	89DT-7D014-EA
2.0	0.079	6	89DT-7D014-FA
2.1	0.083	7	89DT-7D014-GA
2.2	0.087	B	89DT-7D014-MA
2.4	0.094	C	89DT-7D014-JA
2.6	0.102	D	89DT-7D014-KA
2.8	0.110	E	89DT-7D014-LA



61. Install a new hydraulic pump oil seal using Front Pump Alignment Set T74P-77 103-X and Front Pump Seal Replacer T87L-77248-AH or equivalent. Stake the seal in place with tool T87L-77248-BH in 2 places between the existing stakes.




62. Properly position separator plate on converter housing.




63. Properly position two pump gears into pump housing.
64. The inside edge of the small gear has a chamfer on one side. This chamfer must be positioned toward the front of the transmission.

65. The larger gear has a dimple on one side which must be positioned toward the rear of the transmission.




66. Position pump assembly onto separator plate and converter housing.
67. Install bolts finger-tight.



68. Align pump in converter housing using Front Pump Alignment Set T74P-77 103-X or equivalent. This tool must be used in order to prevent seal leakage, gear noise, pump breakage or bushing failure.

69. To use tool, select the arbor with the smallest ID that will fit completely over the pump shaft. Assemble the common handle to the selected arbor and slide the tool down over the shaft until it bottoms against the pump. The outside diameter of the tool arbor will then automatically center the pump in the converter housing.


FRONT PUMP ALIGNMENT SET  
T74P-77103-X



70. With alignment tool installed, tighten five new 6mm hex allen-head pump bolts (E804375-S72M) to 23-27 N-m (17-20 ft-lb).


**CAUTION: Be sure to install new bolts (E804375-S72M).**

71. Remove alignment tool.  
72. Insert the input shaft into the pump and install the converter into the pump gears. Rotate the converter to check for free movement, then remove the converter and input shaft.




73. Coat converter housing gasket with petroleum jelly and position on housing.

74. Install seal on converter housing.




75. Using petroleum jelly, position No. 1 selective washer on rear of pump.  
76. Align converter housing and pump to the transmission.  
77. Install eight 17mm bolts, with new "O" rings, and tighten to 37-52 N-m (27-38 ft-lb).




78. Using Band Adjustment Torque Wrench T71P-77370-A or equivalent, adjust overdrive band.  
79. Install a new lock nut on adjusting screw. Tighten adjusting screw until the tool handle clicks. This is 14 N-m (10 ft-lb).  
80. Back off adjusting screw exactly two turns (2.3L, 2.9L and 3.0L engine applications).  
a. For 4.0L engine applications back off adjusting screw exactly three and a half turns.




81. Hold adjusting screw from turning. Tighten the lock nut to 48-61 N·m (35-45 ft·lb).




82. Following the previous method, adjust the intermediate band backing off the adjusting screw two turns before tightening the lock nut.



83. Install shift lever oil seal using Shift Lever Seal Replacer T74P-77498-A or equivalent.




84. Install internal shift linkage, including external manual control lever, and centering pin. Tighten 7/8 inch nut to 41-54 N·m (30-40 ft·lb).




85. Install O-ring, kickdown lever and 13mm nut. Tighten to 10-14 N·m (7-10 ft·lb).


86. Install neutral start switch using Neutral Start Switch Socket T74P-77247-A "Thin Wall" socket or equivalent. Tighten to 9.5-13.6 N-m (84-120 in-lb).




87. Install converter clutch solenoid connector.



88. Install throttle valve, rod, vacuum diaphragm, retaining clamp and bolt.
89. Be sure the throttle valve moves freely in its bore. Use a pencil magnet to check movement if throttle valve is steel. If throttle valve is aluminum, use the end of a rubber object to check movement.



90. Align valve body to separator plate and gasket using tapered punches.
91. Install two 10mm bolts. Tighten to 9.5-12.1 N-m (84-107 in-lb).
92. Petroleum jelly must be used to keep gasket in proper location on the separator plate during assembly.



93. Remove transmission from holding fixture and place on bench bottom up.
94. Attach and lock the selector lever connecting rod (Z-Link) to the manual valve. Ease control body into the case.



**CAUTION: Use care not to bend selector lever connecting rod (Z-Link).**

Insert correct length bolts, finger-tight, in holes A and B to position control body to case.

95. Insert all remaining bolts (correct length) except the filter screen bolt. Tighten to specification.

96. Remove bolt from hole A and install the detent spring to bolt. Assemble and tighten A and B locations to specification. Install converter clutch solenoid wires.


97. For body bolt locations and sizes, refer to the following illustration.
98. Follow tightening sequence from center of valve body to outer edges.




99. Install the reverse servo piston assembly into servo bore along with a reverse servo check spring D4ZZ-70031-A or equivalent.
100. Install a new servo cover gasket and tool T74P-77 190-A or equivalent and tighten with three attaching bolts.

101. Tighten servo tool adjusting screw to 4 N-m (35 in-lb).
102. Install Dial Indicator with Bracketry TOOL-4201-C on transmission case and position indicator on piston pad. Set dial indicator to zero.

103. Back out the servo tool adjusting screw until piston bottoms out on the tool. Record the distance the servo piston traveled.



104. If piston travel is between 3 and 5.6mm (.120 and .220 inch), it is within specification.




PISTON TRAVEL (X) MUST BE 3-5.6mm (0.120-0.220 INCH)

105. If piston travel is greater than 5.6mm (.220 inch), use the next longer piston and rod.  
 106. If piston travel is less than 3mm (.120 inch), use the next shorter piston and rod.


Length — mm	Length — inches	I.D.
54/53 mm	2.112/2.085	1 Groove
51/50 mm	2.014/1.986	No Groove
49/48 mm	1.915/1.888	2 Grooves

107. Using the above procedure, check the piston travel with the new selected piston and rod (if required) to make sure that the piston travel is between 3 and 5.6mm (.120 to .220 inch).

108. Remove the servo adjusting tool and the reverse servo piston checking spring.  
 109. Install the servo piston assembly, accumulator spring, gasket and cover.  
 110. Install four 10mm servo retaining bolts and tighten to 10-13 N-m (7-10 ft-lb).  
 111. Install new O-rings on the screen and lubricate with petroleum jelly.  
 112. Install filter screen and one 10mm bolt. Tighten to 8-11 N-m (71-97 in-lb).




113. Remove any trace of old gasket on case and oil pan.  
 114. Position oil pan gasket on case and install oil pan.  
 115. Install 18-13mm oil pan retaining bolts. Tighten to 11-13 N-m (8-10 ft-lb).




116. Remove any trace of old gasket on end of case and extension housing.

117. Install parking pawl and its return spring in the extension housing and preload.




118. Using a new gasket, install the extension housing. Be sure to correctly seat the operating parking rod in the extension guide cup.
119. Install six extension housing retaining fasteners. Tighten to 37-52 N·m (27-38 ft·lb).



120. Remove extension housing seal using Extension Housing Seal Remover T71P-7657-A or equivalent.
121. Remove extension housing bushing using Extension Housing Bushing Remover T77L-7697-E or equivalent.
122. Install extension housing bushing using Extension Housing Bushing Replacer T77L-7697-F or equivalent.

123. Install extension housing seal using Extension Housing Seal Replacer T74P-77052-A or equivalent.




## Sub-assemblies

### Valve Body

#### Disassembly

1. Remove three Torx® head screws retaining separator plate and gasket to valve body.



2. With separator plate and gasket removed, note location of:
  - Converter pressure relief valve and spring
  - TV pressure relief valve and spring
  - Three shuttle balls and one check ball
  - Accumulator check valve (two)